

AUTOMOTIVE STYLE CLUTCH

MECHANICAL PTO

Installation & Maintenance Manual



Table of Contents

	Page No.
1.0 INTRODUCTION	4
1.1 WPT Power PTO	
1.2 Product identification numbers	
1.3 Bill of materials	
2.0 SPECIFICATIONS	4
2.1 Flywheel housings	
2.2 Flywheel	
2.3 Maximum RPM and maximum side load	
2.4 Flywheel and flywheel housing alignment tolerances	
3.0 INSPECTION	4
3.1 Preparation	
3.2 Flywheel and flywheel housing alignment	
3.3 Flywheel housing face run out	
3.4 Flywheel housing bore run out	
3.5 Flywheel face run out	
3.6 Engine crankshaft endplay	
4.0 INSTALLATION	6
4.1 Preparation	
4.2 Clutch disc alignment	
4.3 Pressure plate installation	
4.4 PTO alignment to engine	
4.5 Hand hole cover removal	
4.6 Attach PTO to engine	
4.7 Engagement lever installation	
4.8 Clutch adjustment	
4.9 Replace hand hole cover	
5.0 LUBRICATION	6
5.1 Main bearings	
5.2 Operating shaft	
5.3 Ball stud	
5.4 Drawing and parts list reference	
6.0 OPERATION	7
6.1 Engine speed	
6.2 Load	
6.3 Clutch engagement	
6.4 Bring load up to speed	
6.5 Increase engine RPM	
7.0 MAINTENANCE	7
7.1 Engage clutch	
7.2 Hand hole cover removal	
7.3 Check clearance	
7.4 Clutch adjustment	
7.5 Recheck clearance	
7.6 Replace hand hole cover	

Table of Contents

	Page No.
8.0 DISASSEMBLY	8
8.1 Remove PTO from engine	
8.2 Remove clutch from flywheel	
8.3 Remove shaft from PTO housing	
9.0 ASSEMBLY	9
9.1 Install shaft into PTO housing	
9.2 Install clutch disc and pressure plate	
9.3 Attach PTO to engine	
10.0 CHART 1: BOLT TORQUE VALUES	10
11.0 11" PTO DRAWING AND PARTS LIST	11
12.0 13" PTO DRAWING AND PARTS LIST	13
13.0 11" GM® STYLE PTO DRAWING AND PARTS LIST	15
14.0 11" GM® Style High Sideload PTO Drawing and Parts List	17
15.0 11" GM® STYLE PTO Alignment Tool and Spacer Details	19

1.0 INTRODUCTION


- 1.1 The WPT Power PTO is the most rugged PTO available on the market today. Follow the procedures detailed in this Installation and Maintenance Manual for years of service.
- 1.2 When ordering parts, use the part number from the Bill of Materials supplied with this unit. Also, please include the part number and the serial number from the unit itself. These will be found on the metal hand hole cover on the bellhousing. Your WPT Power Distributor can provide a copy of the Bill of Materials if the one provided should become lost.
- 1.3 When performing installation and maintenance functions, refer to the drawings at the back of this manual, pages 11 thru 13. The references on the drawing in this manual DO NOT correspond to the references on the assembly drawing and Bill of Materials. Do not use the item numbers from the drawing in this manual for ordering parts.

2.0 SPECIFICATIONS


- 2.1 Flywheel housings compliant with SAE No. 3, No. 4, GM® style or JEEP® style.
- 2.2 Flywheels compliant with SAE J618 single plate spring loaded clutches.
- 2.3 Refer to the assembly drawing supplied with this unit for maximum RPM and side load. Your WPT Distributor can provide a copy of the drawing if the one provided should become lost.
- 2.4 Flywheel and flywheel housing alignment tolerances see Section 3.0.
- 2.5 Refer to Chart 1 on page 10 for recommended bolt torque values.

3.0 INSPECTION

- 3.1 **Preparation.** Upon receipt of your WPT Power product, inspect for and report any evidence of damage. To avoid damage or personal injury, insure that adequate lifting devices and hand tools are available. Compare the flywheel and flywheel housing to the bell housing, clutch disc and pressure plate, respectively to ensure that you have the correct size unit.
- 3.2 **Check flywheel and flywheel housing alignment.** It is strongly recommended that dial indicator checks be made prior to installation of the PTO, especially on new engines or when a previous PTO failure might indicate an alignment problem.
- 3.3 **Check flywheel to housing face run out.**
Mount the indicator base on the face of the flywheel and position the dial indicator tip perpendicular to the flywheel housing mounting face. Rotate the flywheel 360 degrees while holding pressure against the crankshaft thrust bearing. The total indicator reading should not exceed the values listed in the table shown below in section **3.4 Check flywheel housing bore run out.**



- 3.4 Check flywheel housing bore run out.** Mount the indicator base on the face of the flywheel and position the dial indicator tip so its movement is perpendicular to the pilot bore of the flywheel housing. Rotate the flywheel through 360 degrees.



The total indicator reading should not exceed:

SAE "3" Housing: 0.010 inches (0.254 mm)

SAE "4" Housing: 0.009 inches (0.229 mm)


(Reference: SAE J617 table 1A)

Note: Not applicable for GM® style or JEEP® style housing

- 3.5 Check flywheel face run out.**

Mount the indicator base on the flywheel housing and position the dial indicator tip so that its movement is perpendicular to the face of the flywheel. Position the indicator tip near the pressure plate mounting bolt circle diameter. Rotate the flywheel 360 degrees while holding pressure against the crankshaft thrust bearing.

The total indicator reading should not exceed 0.0005 inches (0.013 mm) per inch of measured diameter.



- 3.6 Check engine crankshaft endplay.**

Measure and document the engine's crankshaft endplay before installing PTO. Using dial indicator as shown in 3.5 move the crankshaft back against the rear main bearing and then move the crankshaft to the front of the engine. Record the total movement as shown by the dial indicator.

4.0 INSTALLATION

NOTE: For units with model number WTD-13-130 or WTD-13-133, the factory flywheel offset is set to standard SAE #3. For alternate offset settings see Section 9.1.

- 4.1 Clean the friction surface of the flywheel and **pressure plate** with an appropriate cleaning solvent to remove any oil and grease.
- 4.2 Use an alignment tool to center the **clutch plate** on the flywheel, if necessary. The pressure plate side of the clutch plate should face out.

NOTE: For the PTO's with model number WTD-11-143 or WTD-11-144, see Section 14 for complete alignment tool details.

- 4.3 Place the **pressure plate** and **clutch plate** in position on the flywheel and assemble using grade 8 bolts. Make sure alignment tool is in place, and then tighten the bolts evenly in an alternating pattern. Torque bolts to the specifications in Chart 1 on page 10 or to the engine manufacturer's torque. Use the engine manufacturer's torque recommendation if different from that in Chart 1. The alignment tool can now be removed.



CAUTION:

The PTO is heavy. Use approved lifting equipment and procedures to prevent accident or injury.

- 4.4 Insert guide pins into the engine flange face 180° apart in order to properly align the PTO **bellhousing** and **shaft** with the engine.
- 4.5 Remove inspection **hand hole cover** from the PTO **bellhousing**. Align the PTO **bellhousing** and **shaft** parallel with the engine crankshaft.
- 4.6 Advance the PTO **bellhousing** onto the guide pins carefully. Continue until it is against the engine flywheel housing. Remove the guide pins and install grade 5 or better hex head cap screws to attach the bellhousing to the engine. Torque bolts to the specifications in Chart 1 on page 10 or to the engine manufacturer's torque. Use the engine manufacturer's torque recommendation if different from that in Chart 1.
- 4.7 Place the **hand lever** on the desired side of the operating **shaft**. Secure with the appropriate **hex head cap screw**. The **hand lever** should be at a 5° to 10° angle from vertical toward the engine when the clutch is completely disengaged, see appropriate drawing at the back of this manual, page 11.
- 4.8 For initial adjustment of clutch: See adjustment instruction in Section 7.0.
- 4.9 Replace **hand hole cover** and attach with screws prior to use.



WARNING:

The WPT mechanical PTO is capable of side load and inline power transmission applications. Special care should be exercised when installing the PTO in an inline application. Due to engine movement and other factors that may cause misalignment, WPT recommends that a flexible coupling or drive shaft be used to join the PTO and driven shaft. If a coupling is used, ensure that it has sufficient horsepower capacity and that shafts are in line within the limits specified by the coupling manufacturer. If you are unsure about the procedure to align these shafts, consult the coupling manufacturer or WPT Power.


5.0 LUBRICATION

- 5.1 The **throw-out bearing** and **main bearings** are sealed for life and require no lubrication except WTD-11-143 & WTD-11-144 units pack using EP-2 Lithium based grease or equal every 300 hours. However, they should be inspected every two years for wear or damage.
- 5.2 Apply one shot of grease every 100 hours of use to all **fittings** on the operating shaft. Use a good quality lithium-based grease (300°F minimum drop point, No. 2 NGLI).

5.3 During adjustment, apply a small amount of grease to the **ball stud** to prevent wear and corrosion.

5.4 Please refer to pages in the back of this manual for a drawing and parts list for this PTO.

6.0 OPERATION

 **WARNING:** If the **hand lever** has no free play present before the clutch is engaged, adjust, as necessary. See clutch adjustment, Section 7.0.


6.1 Start the engine and idle at low speed (1000 rpm or less).

6.2 Machinery to be driven should be under no load.


6.3 Use one single swift movement of the hand lever to engage the clutch. Do not allow the clutch to slip for longer than 2 seconds without either completely engaging it or completely disengaging it.


6.4 If the load to be driven has a large inertia to overcome, the clutch may need to be slipped several times (a.k.a. "bumping-in") to bring the driven load up to speed. After 3 to 4 slips, engage the hand lever fully.

6.5 Once the load is turning with the clutch fully engaged, the engine RPM may be increased.

 **WARNING:** Engagement at engine speeds above 1000 rpm will reduce clutch life and may cause damage to driven machinery.

7.0 MAINTENANCE

 **WARNING:** In order for the clutch **release bearing** to not contact the release fingers when the clutch is fully engaged, the clutch should be adjusted periodically.

 **CAUTION:** Turn off engine and prevent from being restarted while adjustments are being performed.

7.1 Fully engage the clutch.

7.2 Remove **hand hole cover**.

7.3 Check the clearance between the clutch release fingers and the **throw-out bearing** surface, as specified on drawing supplied with this unit. Your WPT distributor can provide a copy of the drawing if the one provided should become lost.

7.4 Loosen the **jam nut** and rotate the **ball end adjust** as needed to obtain the proper clearance.

7.5 Recheck clearance after **jam nut** has been tightened.

7.6 Replace **hand hole cover**.

8.0 DISASSEMBLY

(Refer to PTO Illustration on pages 11-19 of this manual)

Use a hoist or other suitable lifting equipment to support the weight of the power take-off. Attach lifting devices at several places or use cribbing to support the PTO in a horizontal position during removal.



CAUTION:

The PTO is heavy. Use approved lifting equipment and procedures to prevent accident or injury.

8.1 Remove the PTO from the engine.

8.1.1 Remove **hand lever** and other connections to the PTO.

8.1.2 Remove drive shaft or drive belts from PTO output shaft.

8.1.3 Remove the mounting bolts attaching PTO to flywheel housing, removing those located near the top last. The PTO should separate from the flywheel housing. If the PTO doesn't separate, gently pry the flanges apart until the housing is removed from the engine flywheel housing pilot diameter.



WARNING: Use care when removing the PTO from the engine to avoid damage to **grease fittings, shaft splines, and other components.**

8.2 Remove the clutch from the flywheel.

8.2.1 Remove bolts holding the **pressure plate** and **clutch plate** to the flywheel.

8.2.2 Remove **pressure plate** and **clutch plate**.

8.3 Remove the shaft from the PTO housing.

8.3.1 Place the assembly in a position to have access inside **bellhousing**.

8.3.2 Remove **spring, fork** and **throw-out bearing sleeve** from housing assembly.

8.3.3 Remove **engagement cam assembly** from **bellhousing**. Remove **bolts** and slide **engagement shaft** out of **bellhousing**.

8.3.4 Remove **bolts** from **bearing carrier**.

8.3.5 Strike output end of **shaft** with soft faced hammer or use a suitable bearing press to loosen **shaft, bearings** and **bearing carrier** from PTO **bellhousing**.

8.3.6 Remove **bearing carrier** and **shaft** with **bearings** from PTO **bellhousing**.

8.3.7 Remove **bearing carrier** from **shaft** and **bearings** using a suitable bearing press.

8.3.8 Using a suitable bearing press, remove **bearings** from shaft.


9.0 ASSEMBLY

9.1 Alternate flywheel offset setting for WTD-13-130 & WTD-13-133 only.

- 9.1.1 Remove return spring from throw-out fork.
- 9.1.2 Remove throw-out fork from ball end adjusting stud.
- 9.1.3 Ensure fork stud is out of thrust bearing groove.

NOTE: Ball end socket is engaged on "A" side from factory.

- 9.1.4 Reverse throw-out fork to engage alternate ball end socket. Ball engaged on "B" side.



- 9.1.5 Ensure fork stud is inside throw-out bearing groove.
- 9.1.6 Insert ball end stud into ball socket of throw-out fork on "B" side.
- 9.1.7 Secure return spring to throw-out fork.
- 9.1.8 Check clearance and adjust as needed see Section 7.0.

9.2 Assembly of the unit


- 9.2.1 Install **shaft** into PTO **bellhousing** by reversing steps found in Section 8.3.
- 9.2.2 Install **clutch plate** and **pressure plate** to flywheel following instructions 4.1 thru 4.3.
- 9.2.3 Install shaft and housing assembly following instructions 4.4 thru 4.7.
- 9.2.4 Adjust clutch as indicated in instructions 7.0 **MAINTENANCE**.

10.0 CHART 1


TORQUE VALUES FOR HEX HEAD CAP SCREWS (HHCS)						
HEX HEAD CAP SCREWS - Grade 8						
BOLT SIZE IN INCHES	As Received			Lubricated**		
	LB - FT	LB - IN	Nm	LB - FT	LB - IN	Nm
1/4 -20	8	100	11	6	80	9
5/16-18	17	200	23	13	160	18
3/8 -16	30	360	41	24	288	32
7/16-14	48	570	64	38	456	51
1/2 -13	83	990	112	66	792	89
9/16-12	107	1285	145	85	1028	116
5/8 -11	143	1714	194	114	1371	155
3/4 -10	256	3070	347	204	2456	277
7/8 -9	417	5000	565	333	4000	452
1 -8	625	7500	847	500	6000	678
1 1/8-7	770	9240	1040	616	7390	835
1 1/4-7	1090	13100	1480	869	10400	1180
1 3/8-6	1430	17200	1940	1140	13700	1550
1 1/2-6	1890	22700	2560	1510	18100	2050
HEX HEAD CAP SCREWS - Grade 5						
BOLT SIZE IN INCHES	As Received			Lubricated**		
	LB - FT	LB - IN	Nm	LB - FT	LB - IN	Nm
1/4 -20	6	71	8	5	56	6
5/16-18	12	142	16	9	113	12
3/8 -16	22	260	29	17	208	23
7/16-14	34	410	46	27	328	36
1/2 -13	53	636	72	42	508	57
9/16-12	74	890	101	59	712	80
5/8 -11	104	1250	141	83	1000	112
3/4 -10	183	2200	249	146	1760	199
7/8 -9	298	3570	403	238	2856	322
1 -8	440	5280	597	352	4224	477
1 1/8-7	553	6640	750	442	5312	600
1 1/4-7	775	9300	1051	620	7440	840
1 3/8-6	1012	12140	1372	809	9712	1097
1 1/2-6	1350	16200	1831	1080	12960	1464
** NOTE: For Loctite use lubricated values						


TORQUE VALUES FOR SOCKET HEAD CAP SCREWS (SHCS)						
BOLT SIZE IN INCHES	As Received			Lubricated**		
	LB - FT	LB - IN	Nm	LB - FT	LB - IN	Nm
1/4 -20	13	150	17	10	120	13
5/16-18	23	305	34	18	244	27
3/8 -16	45	545	62	36	436	49
7/16-14	70	840	95	56	672	76
1/2 -13	108	1300	147	86	1040	117
9/16-12	155	1860	210	124	1488	168
5/8 -11	211	2530	286	168	2024	228
3/4 -10	367	4400	497	293	3520	397
7/8 -9	583	7000	791	466	5600	632
1 -8	867	10400	1175	693	8320	940
1 1/8-7	1242	14900	1684	993	11920	1347
1 1/4-7	1750	21000	2374	1400	16800	1899
1 3/8-6	2317	27800	3142	1853	22240	2513
1 1/2-6	3042	36500	4125	2433	29200	3300
1 3/4-5	4950	59400	6714	3960	47520	5371
2-4.5	7492	89900	10161	5993	71920	8128
** NOTE: For Loctite use lubricated values						

11.0 11" PTO Drawing and Parts List



Jeep Style (WTD-11-148 Shown)







Jeep Style (WTD-11-148 Shown)

#	Description	#	Description
1	ASSEMBLY,CLUTCH PLATE	18	BRG,OUTBOARD
2	ASSEMBLY,PRESSURE PLATE	19	BRG ENDCAP
3	BRG,THRUST	20	SHAFT
4	FORK,THROW-OUT	21	KEY
5	HHCS	22	CAP,GREASE FITTING
6	WASHER,LOCK	23	ZERK
7	BRG CARRIER	24	ENGAGEMENT CAM
8	BRG,INBOARD	25	KEY,WOODRUFF
9	BALL END ADJUST	26	SHAFT,OPERATING
10	HEX NUT	27	SET SCREW
11	SPRING,EXTENSION	28	PLUG,PIPE (not Shown)
12	SCREW,SPRING ANCHOR	29	ACCESS COVER
13	BELLHOUSING	30	DUST COVER
14	ASSEMBLY,LEVER,HAND	31	HHCS
15	NAMEPLATE	32	HHCS
16	HHCS	33	HHCS
17	STUD,THREADED ADJUST	34	ADAPTER, SPEED SENSOR

12.0 13" PTO Drawing and Parts List




13" Flat Face Flywheel (WTD-13-130 shown)




13" Flat Face Flywheel (WTD-13-130 shown)

#	Description	#	Description
1	CLUTCH PLATE	14	STUD,BALL END ADJUST
2	PRESSURE PLATE	15	ASSEMBLY,LEVER,HAND
3	BRG,THRUST	16	BELLOUSING
4	FORK,THROW-OUT	17	RODENT COVER
5	HHCS	18	HAND HOLE COVER
6	WASHER,LOCK	19	SHCS
7	BRG CARRIER	20	HEX NUT
8	BRG,INBOARD	21	SEAL,OUTPUT SHAFT
9	SHAFT	22	CAP,GREASE FITTING
10	KEY,OUTPUT	23	ZERK
11	BRG,OUTBOARD	24	ENGAGEMENT CAM ASSY
12	SPRING,EXTENSION	25	KEY,WOODRUFF
13	SCREW,SPRING ANCHOR	26	SHAFT,OPERATING

13.0 11" GM® Style PTO Drawing and Parts List







GM Style (WTD-11-143 shown)

#	Description	#	Description
1	HHCS	15	BELLOUSING
2	DUST COVER	16	ASSEMBLY,LEVER,HAND
3	ASSEMBLY,CLUTCH PLATE	17	NAMEPLATE
4	ASSEMBLY,PRESSURE PLATE	18	STUD,THREADED ADJUST
5	BRG,THRUST	19	BRG,OUTBOARD
6	FORK,THROW-OUT	20	BRG ENDCAP
7	HHCS	21	SHAFT,AUTOMOTIVE STYLE
8	WASHER,LOCK	22	KEY
9	BRG CARRIER	23	CAP,GREASE FITTING
10	BRG,INBOARD	24	ZERK
11	BALL END ADJUST	25	ENGAGEMENT CAM
12	HEX NUT	26	KEY,WOODRUFF
13	SPRING,EXTENSION	27	SHAFT,OPERATING
14	SCREW,SPRING ANCHOR	28	SET SCREW

14.0 11" GM® Style High Sideload PTO Drawing and Parts List




Note: Add grease during installation to Labyrinth Seal when replacing.




#	Description	#	Description
1	HHCS	16	BELLOUSING
2	DUST COVER	17	ASSEMBLY, LEVER, HAND
3	ASSEMBLY, CLUTCH PLATE	18	NAMEPLATE
4	ASSEMBLY, PRESSURE PLATE	19	STUD, THREADED ADJUST
5	SEAL, GREASE, LABYRINTH	20	BRG, SPHERICAL ROLLER
6	BRG, THRUST	21	BRG ENDCAP
7	FORK, THROW-OUT	22	SHAFT
8	HHCS	23	KEY
9	WASHER, LOCK	24	CAP, GREASE FITTING
10	BRG CARRIER	25	ZERK
11	BRG, SPHERICAL ROLLER	26	ENGAGEMENT CAM
12	BALL END ADJUST	27	KEY, WOODRUFF
13	HEX NUT	28	SHAFT, OPERATING
14	SPRING, EXTENSION	29	SET SCREW
15	SCREW, SPRING ANCHOR		

15.0 11" GM® Style (WTD-11-143 & WTD-11-144) Alignment Tool and Spacer Details

Alignment Tool – Can be purchase at most automotive part stores with the Doorman part number 14522 or with the Centerforce part number 50028. If unavailable at a local automotive part store, WPT can be contacted with part number WTD-11-A49.



Flywheel Spacer – Can be made at a local machine shop from mild steel using the drawing below or call WPT to purchase part number WTD-11-A66.





WPT Power
1600 Fisher Road - Wichita Falls, TX 76305
P.O. Box 8148 - Wichita Falls, TX 76307 Ph. 940-761-1971
www.WPTpower.com